


Spare Parts
<b>Rotating nozzle ST-458.1</b>
Item-No. 20 0458 6 . .



Pos.	Item-No.	Description
1	02 0001 025	Protection cap
2	01 0001 070	Housing brass
3	05 0001 360	O-ring for ceramic seat
4	05 0001 070	O-ring for inlet
5.1	01 0001 088	Inlet complete brass 030
5.2	01 0001 085	Inlet complete brass 035
5.3	01 0001 086	Inlet complete brass 040
5.4	01 0001 087	Inlet complete brass 045/050/055/070
5.5	01 0001 089	Inlet complete brass 060/065/080/090/100

Pos.	Item-No.	Description
6.1	20 0458 230	Repair-kit with nozzle 030 (yellow)
6.2	20 0458 235	Repair-kit with nozzle 035 (dark blue)
6.3	20 0458 240	Repair-kit with nozzle 040 (brown)
6.4	20 0458 245	Repair-kit with nozzle 045 (nature)
6.5	20 0458 250	Repair-kit with nozzle 050 (black)
6.6	20 0458 255	Repair-kit with nozzle 055 (light blue)
6.7	20 0458 260	Repair-kit with nozzle 060 (red)
6.8	20 0458 265	Repair-kit with nozzle 065 (dark grey)
6.9	20 0458 270	Repair-kit with nozzle 070 (white)
6.10	20 0458 280	Repair-kit with nozzle 080 (orange)
6.11	20 0458 290	Repair-kit with nozzle 090 (grün)
6.12	20 0458 210	Repair-kit with nozzle 100 (beige)