


Spare Parts
Bypass Injector ST-167
 Item-No. 20 0167 501



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	04 0003 615	Inlet nut ST-168	14	04 0003 558	Screw plug
2	05 0002 330	O-Ring 27x1,5	15	04 0003 605	Housing ST-168
3	06 0000 960	Spring	16	04 0003 625	Hose clip
4	05 0002 450	Seal ring	17	04 0003 515	Nozzle
5	02 0005 093	Protection ring	18	05 0000 520	O-Ring Viton
6	02 0005 092	Locating disc	19	04 0003 635	Trigger ST-168
7	04 0003 535	Injector nozzle	20	02 0005 115	Ball handle
8	04 0003 550	Hose clip			
9	02 0005 100	cover blue			
10	05 0000 301	O-ring 10.82 x 1.78			
11	04 0003 555	Check valve piston			
12	05 0000 265	O-ring 2,9x1,78			
13	06 0001 100	Spring			

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					